





HANDMADE AND MORE

4

backrest

attach velcro tape (only loops) to the inside of the grey area
bottom part is tuck through the backrest and the seating surface

8

arm side

attach velcro tape (only loops) to the inside of the grey area
bottom part is tuck through the arm rest side and the seating surface

side

attach velcro tape (only loops) to the inside of the grey area
bottom part is wrapped around the side and secured on the bottom of the chair

7